

VALID FOR: RETROWRAP STD2, HD2, X, T, SL



## Packing at CCI Oy:

Each wrap is rolled, tied, and placed into its dedicated wooden crate.

Packing, Handling & Storage Recommendations

- Crates are made according to wrap size and a layer of plastic sheet is placed inside the crate.
- The crate is marked and labeled displaying the content, according to agreed project applicable marking and labeling guidelines.

# Example of typical crate



### Storage Procedure at CCI Oy:

- When crate is packed, the lid is attached
- Crates are moved to warehouse awaiting shipment
- All crates are moved by using a forklift

#### CUSTOMER receiving the container or crates on site containing the Retrowraps:

- Use a fork lift to remove the crates form the container
- Crates should be moved to a storage where they aren't exposed to direct sunlight
- Crates can be stored on top of each other, max 3 crates on each other
- The temperature of the warehouse should not exceed + 50 C°
- Avoid storing the crates in a dusted environment

#### **CUSTOMER Handling / Unpacking of the crates:**

- When opening the crates, remove the fastening screws from the lid
- Lift the lid of the crate, lift by hand (rec. 2 persons) the needed Retrowraps out of the crate and move them to desired location. Wrap weight varying depending on wrap size and are typically within 20 – 60 kg each. Use of gloves is recommended.
- Do not leave the removed wraps exposed to direct sunlight and do not place them directly onto tarmac !
- Be careful not to subject wrap to sharp objects that can damage or puncture the outer surface layer!

#### Identification of wraps

• Each Retrowrap is labeled with a sticker or mark showing the specific wrap identification number or serial number, if agreed in project applicable marking and labeling guidelines.

Products Designed and Sold by: